


PacWeigh TP Logger

Do you need immediate access to the current scale transactions to properly manage your production?


Do you want to stop relying on one person to collect your data from the scale indicator?

PacWeigh TP Logger provides real


time data collection for manned or unmanned truck scale operations running Truck and Product In/Out application on the GSE 560 or a GSE 660 series indicator. PacWeigh TP Logger will collect your transaction in one central database making it easier and safer to manager your



Easily see the last transaction that occurred on the scale and what is in the yard.



View the transactions that have occurred. Filter the data and export to Excel or produce a report.



Entry window for maintaining trucks or cards

TP Logger also provides a streamlined interface for maintaining the truck and product supporting tables.

Even in the event of communications failure between the scale indicator and PacWeigh TP Logger collection system the scale will continue to collect data and send it as soon as the communication line is restored



System Requirements

Indicator

Model GSE560 or GSE660 Series
Application Truck and Product In/Out Manned or Unmanned


Communications

Interface RS232 to TCP

PC Logger

OS Windows XP Professional or Windows Vista Business
PC Uptime 24hours a day
Database Microsoft SQL Server 2005 or Microsoft SQL Server 2005 Express Edition

Overview of Device Connections



Head Office - Richmond

Toll Free 1-800-233-9401
Phone 604-273-9401
Fax 604-273-8467
Email info@pacific-scale.com

Calgary Branch

Toll Free 1-888-787-2253
Phone 403-250-7228
Fax 403-250-2620
Email info@pacific-scale.com

Edmonton Branch

Toll Free 1-888-897-2253
Phone 780-438-5578
Fax 780-437-5656
Email info@pacific-scale.com

Additional service branches are located in Prince George, Terrace, Kelowna and Nanaimo

WWW.PACIFIC-SCALE.COM

1-800-233-9401